


# Faber

Dry Iron  
FDI-108



VOLTAGE: 220-240V FREQUENCY : 50-60Hz POWER RATED: 1000W

## INSTRUCTION MANUAL

PLEASE READ THIS INSTRUCTIONS MANUAL CAREFULLY BEFORE USING THIS PRODUCT

# CONTENTS

<b>Title</b>	<b>Page No.</b>
Safety Precautions	2
Technical Specifications	3
Parts Introduction	4
Operating Instructions	4
Cleaning and Maintenance	5

## SAFETY PRECAUTIONS

1. Ensure that the voltage range shown on the appliance rating label corresponds to the main power supply's voltage.
2. This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
3. To prevent damage to the cord, do not pull or wrap it around the appliance and ensure it is stored without twisting or folding it.
4. Do not operate the appliance with a damaged power cord or power plug. Return the appliance for examination, adjustments, or repair.
5. Unplug the unit when not in use and whenever you clean or move the unit.
6. To disconnect the appliance, grip the power plug and pull it from the power outlet. Never yank on the power cord.
7. Only authorized service personnel should be allowed to undertake repairs on electrical appliances. Repairs undertaken by unauthorized persons may result in damage to the appliance and/or accidents or injury to the user.
8. If the power supply cord is damaged, have it replaced by the manufacturer its service agent, or a similarly qualified person to avoid a hazard.
9. High temperature is generated during use, which may result in burns or other injuries.


10. The iron should never be left unattended while it is still connected to the power supply.
11. Always use the handle and warn others (especially children) of the possible dangers (e.g. burns from steam or hot water, especially when ironing vertically).
12. The iron should be used strictly in accordance with these instructions. We will not accept liability for any damage caused by non-compliance with these instructions, or any other improper use or mishandling.
13. **CAUTION:** Ironing over zippers/rivets on jeans, etc. may scratch or damage the soleplate.

## TECHNICAL SPECIFICATIONS

Model	FDI-108
Power Supply	220-240V~ 50-60Hz
Power Consumption	1000W
Product Size	255(L) x 110(W) x 125(H)MM

## PARTS INTRODUCTION

### Control Panel



## OPERATING INSTRUCTIONS

### **Before the First Use**

Before operating the appliance, ensure that the voltage indicated on the appliance matches the mains voltage in your home. If there is any discrepancy or if the voltage is not stated, do not use the appliance and contact your dealer for assistance.

If there is a sticker or protective foil on the soleplate, remove it before using the iron.

## Temperature Setting Guide

1. Before ironing, sort your garments according to their care labels. Begin with fabrics that require the lowest temperature setting and gradually move to those needing higher temperatures. This approach is recommended as the iron heats up more quickly than it cools down.
2. Refer to the "Temperature Setting Guide" to select the appropriate heat level for each fabric type.
  - a. **Low Heat (●):** Suitable for synthetic fabrics such as nylon, acetate, and acrylic.
  - b. **Medium Heat (●●):** Suitable for silk, wool and polyester blends.
  - c. **High Heat (●●●MAX):** Suitable for cotton, linen, and other durable fabrics.
3. Once the indicator light turns off, the iron has reached the desired temperature and is ready for use.

## CLEANING & MAINTENANCE

1. Before cleaning, turn the temperature knob to position "OFF" and unplug the power. Stand the iron upright and let the iron to cool completely before it is cleaned and stored.
2. The appliance can be cleaned with a damp cloth. Do not use abrasives on the soleplate.
3. Wipe the soleplate with a damp cloth and a non-abrasive cleaner.
4. Ironing over zippers/rivets on jeans, etc may scratch the soleplate.
5. **CAUTION:** Never use scouring pads, abrasive or harsh cleaners as this may scratch the surface.





This marking indicates that this product should not be disposed with other household wastes throughout the nation. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



Dibuat untuk dan diedarkan oleh:  
FIMACO SDN BHD  
8-2, WISMA FIAMMA,  
No.20, Jalan 7A/62A,  
Bandar Manjalara, 52200 Kuala Lumpur, Malaysia.  
CUSTOMER CARE CENTRE: +603 6279 8888

