


# FABER

*Living the Italian Style*

MINI CHOPPER

INSTRUCTION MANUAL

FCB 520



Read this booklet thoroughly before using and save it for future reference


## **IMPORTANT SAFETY INSTRUCTIONS**

- Read all instructions before using.
- Do not open until blades stop.
- The attached motor unit can not be used for other than intended use.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not let the cord hang over the edge of a table or counter or touch a hot surface.
- Do not place on or near a hot gas or electric burner or in a heated oven.
- keep hands and utensils away from the cutting blade while chopping food to reduce the risk of severe injury to persons or damage to the food chopper. A scraper may be used but only when the food chopper is not running.
- To protect against a fire, electric shock or personal injury, do not immerse cord, electric plugs, or motor unit in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- The appliance is not a toy. Do not let the children play it.
- Avoid contacting moving parts.
- The use of attachments not recommended or sold by manufacturer may cause fire, electric shock or injury.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner, Return appliance to the nearest authorized service facility for examination, repair or electrical or mechanical adjustment.
- Do not use the appliance for other than intended use.
- Be sure motor unit is locked securely in place before operating appliance.
- Do not attempt to defeat the lid interlock mechanism.
- Do not use outdoors.
- **SAVE THESE INSTRUCTION.**

**DO NOT OPEN UNTIL BLADES STOP.**

# HOUSEHOLD USE ONLY

## KNOW YOUR FOOD CHOPPER



## BEFORE THE FIRST USE

Before using this appliance for the first time, wash the bowl and blade assembly in sudsy water and dry thoroughly, all of these parts are safe in dishwasher, wipe the motor unit with a damp cloth, do not immerse the motor unit in water.

## HOW TO CHOP OR MINCE FOOD

1. Place the bowl on a counter or other flat surface, then slide the blade down over the shaft in the bowl. Be careful not to touch the blade as it is extremely sharp.
2. Place dry food in the bowl, the desired food refers to the chopping guide.
3. Position the motor unit onto the bowl, lining up the motor unit locking tabs to the

bowl locking slots till the motor unit locks.

Note: For your protection, this unit has a lid locking system, the unit will not operate unless the tabs in the motor unit and slots in the bowl align. Do not attempt to operate the unit without locking the motor unit in place.

4. Depress and hold the pulse button to process.

Note: This product has a “pulse action” feature. Avoid running the motor continuously in this mode for period over 30seconds. the longer the continuous pulse, the finer the texture. For coarsely chopped foods, use short pulses.

5. Be sure the blade stops rotating completely before removing the motor unit. Unplug the unit. Remove the motor unit and grasp the plastic blade hub. carefully pull the blade assembly out. Remove the bowl and empty the processed food. Do not use bowl for storing food.

## CLEANING AND MAINTENANCE

Always disconnect the appliance from the power outlet before cleaning.

Wash the bowl, blade assembly immediately after use either with warm/sudsy water or in the dishwasher. Wipe off the motor unit with a damp cloth- do not immerse in water.

**NOTE:** Do not use chemical, steel, wooden or abrasive cleaners to clean the unit to prevent the gloss loss.

## CHOPPING GUIDE

FOOD TYPE	PREPARATION HINTS
Fruits and vegetables Canned Cooked	Drain up to 120g and process 10seconds ON 2min OFF until pureed as desired. Use up to 120g plus cooking liquid as needed and process ON 10seconds OFF 2min until pureed is desired Pulse or process up to 120g chunked fruits or vegetables ON 10seconds OFF 2min until desired chop is reached.
Fresh Parsley and other leafy herbs	Wash and dry thoroughly then pulse or process up to 120g ON 10seconds OFF 2min until desired chop is achieved.
nuts	Pulse or process up to 120g ON 10seconds OFF 2min until desired chop is reached.
Cookies, crackers	Pulse or process up to 12 cookies or crackers ON 10seconds OFF 2min until desired chop is reached.

Fresh beef or pork Cut into 30mm*15mm*15mm bulk	Pulse or process up to 120g beef or 120g pork ON 15seconds OFF 2min until desired chop is reached.
Stir the maltose	60g maltose and 20g honey ON 5 seconds OFF 2min until desired chop is reached.

## ENVIRONMENT FRIENDLY DISPOSAL



You can help protect the environment!

Please remember to respect the local regulations: hand in the non-working electrical equipments to an appropriate waste disposal center.





